

## Pocket Door System

### SINGLE POCKET DOORS






#### General Notes:

Not to Scale

Due to continual product development, detail and technical data are subject to change without notice
For latest product specifications please go to our website: www.intlwindow.com or contact your IWC Representative
This is an architectural view of cross sections only and installation of shims, fasteners and sealant shall be the responsibility of the installer



# Pocket Door System




#### General Notes:

Not to Scale

Due to continual product development, detail and technical data are subject to change without notice
For latest product specifications please go to our website: www.intlwindow.com or contact your IWC Representative
This is an architectural view of cross sections only and installation of shims, fasteners and sealant shall be the responsibility of the installer



## Pocket Door System



#### General Notes:


Not to Scale

Due to continual product development, detail and technical data are subject to change without notice
For latest product specifications please go to our website: www.intlwindow.com or contact your IWC Representative

This is an architectural view of cross sections only and installation of shims, fasteners and sealant shall be the responsibility of the installer



## Pocket Door System




#### General Notes:

Not to Scale

Due to continual product development, detail and technical data are subject to change without notice
For latest product specifications please go to our website: www.intlwindow.com or contact your IWC Representative
This is an architectural view of cross sections only and installation of shims, fasteners and sealant shall be the responsibility of the installer



# Pocket Door System



#### General Notes:

Not to Scale

Due to continual product development, detail and technical data are subject to change without notice

For latest product specifications please go to our website: www.intlwindow.com or contact your IWC Representative

This is an architectural view of cross sections only and installation of shims, fasteners and sealant shall be the responsibility of the installer

